


G7&K3 FAQ

1. How to reset G7 or K3

Please use the pin to press the reset button for more than 5 seconds, then release it. It is successful when hearing the “Di” sound.



2. Forget the password

Please reset the camera to restore the default password, then click “Help” to reconfigure .

3. Camera is offline when changing router or password.

Please reset the camera, then click “Help” to reconfigure .

4. How many users are supported to be online and check live video or playback at the same time?

It supports 4 users for staying online, 2 for checking live video and 1 for checking playback at the same time.

5. How to configure E-mail

as an example:

- Login your Gmail
- Click “forwarding and pop/” in setting, and select “Enable POP for all mail” or check “Enable ”
- Go to App→Setting→Email setup, choose Gmail, enter Email and password
- Do E-mail test
- It is successful when getting the test E-mail.

6. How long will it record with 32GB SD card?

It will record about 72 hours under “Clear” situation and 11 days under “Fluent” situation.

7. What’s the capacity of memory card supported for the camera?

It supported from 8GB to 128GB.

8. G7&K3 Camera’s viewing angle

- 1) G7: pan (110°) and tilt (130°)
- 2) K3: pan (120°) and tilt (140°)